



- dia 32mm holes: drill outer two first, then take out middle part (this hole can be bigger without consequences)
- NOTE: THE HOLES ARE NOT IN THE MIDDLE! DRAWN IS FRONT
- Ø2mm holes: user needs to drill 4 of 8 depending on the way of mounting:
 - fixing frame with screws: use holes (1)
 - fixing housing with threaded bar and wingnuts: use holes (2)

Dimensions in mm

